




SmartBuckle




SmartBucklePremium

Sheet 1:	Connections
Sheet 2:	nRF9160
Sheet 3:	nRF52832 MCU
Sheet 4:	Sensors and LEDs
Sheet 5:	Power Supply




PROJECT NAME: Premium		REV: 6
PAGE DESCRIPTION: *		
Drawn by: D. Sanderson	Date drawn: *	
SHEET: 1 OF 6		





AUX UART is for WiFi chip debug logs, RF tests and flashing



R11 is used to put WiFi chip in program mode DNP for normal operation

